

# MORE TO ADORE

## Converted Door Headboard

Discover a door's full potential by converting it into a headboard crowned with decorative molding and painted to enhance your décor.

### You'll Need:

---

Dutch Boy® Cabinet, Door & Trim paint (2 colors)	Painter's tape
Wooden interior door	Wood filler
Decorative trim molding (precut the height of the door)	Putty knife
Flat paintbrush	Wood glue or all-purpose adhesive
Mini woven roller cover and roller frame	Fine- to medium-grit sandpaper
Mini trays	Hammer
	Finishing nails
	Clean, damp cloth

### Here's How:

---

- Step 1** Prep the door by filling oversized areas, such as doorknob holes, with a piece of wood cut to size and glued into place; fill smaller holes with wood filler and the putty knife to create a smooth surface; allow to dry completely.
- Step 2** Use wood glue to adhere decorative molding to the top of the outward facing part of the door; wipe away excess glue with clean, damp cloth; insert finishing nails with the hammer every few inches; apply wood filler over nail holes.
- Step 3** Lightly sand any rough or glossy surfaces; wipe with clean, damp cloth to remove dust or debris.
- Step 4** Using the mini woven roller, paint the outer frame; use the flat brush to paint the decorative trim and hard-to-reach areas with the first paint color; allow paint to dry 24 hours.
- Step 5** Affix painter's tape just outside each door panel; using the flat brush, paint the recessed panels with the second color.  
*Optional: Apply a second coat of paint for added coverage.*
- Step 6** Remove painter's tape while paint is still damp; clean up any mistakes with the clean, damp cloth; allow paint to dry, following suggested drying time on paint can label.
- Step 7** Install headboard.

Find more paint projects at [menards.dutchboy.com/projects](http://menards.dutchboy.com/projects).

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Wall: Urchin Shell 220-3DB  
Headboard Trim: White 003W