

MAKE AN ENTRANCE

Painted Accent Door

Place color in just the right place with an accented interior door — an unexpected alternative to an accent wall.

You'll Need:

Dutch Boy® Cabinet, Door & Trim paint	Fine- to medium-grit sandpaper
Angled paintbrush	Screwdriver
Mini woven roller cover and roller frame	Drop cloth
Mini trays	Clean, damp cloth
Painter's tape	

Here's How:

-
- Step 1** Remove door hardware; use the sandpaper to sand any rough or glossy surfaces on the door; wipe with clean, damp cloth to prepare painting surface.
- Step 2** Lay down the drop cloth to protect floors.
- Step 3** Affix painter's tape around doorframe and over hinges; apply pressure to tape to ensure a tight seal.
- Step 4** Using the angled brush, paint door panels and any hard-to-reach areas; paint remainder of the door with the mini woven roller.
- Step 5** Remove painter's tape while paint is still damp; allow paint to dry, following suggested drying time on the can label.
- Step 6** Reattach door hardware.

Find more paint projects at menards.dutchboy.com/projects.

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Door: **Pinked Azalea 103-6DB**
Walls: **Whispered White 019W**
Stripe: **Mousey Tint 441-1DB**