

FOLLOW THE BAND

Single Bold Stripe

Rescue plain walls with an exaggerated single stripe of color in a bold or subtle contrasting shade (as shown here).

You'll Need:

Dutch Boy® Platinum® Plus paint (2 colors)	Tape measure
Angled paintbrush	Pencil
Woven roller covers and roller frame	Level
Paint tray and liners	Drop cloth
Painter's tape	Clean, damp cloth

Here's How:

- Step 1** Wipe walls with the clean, damp cloth to prepare painting surface.
- Step 2** Lay down a drop cloth to protect floors; affix painter's tape to baseboards, ceiling and any molding or trim.
- Step 3** Apply paint just inside taped areas with the angled brush, then paint the remainder of the walls with the woven roller; remove painter's tape while paint is still damp; allow paint to dry 24 hours.
- Step 4** Decide on stripe width and lightly mark with the pencil the top and bottom of the stripe; use the level to lightly draw horizontal stripe lines along walls.
- Step 5** Affix edge of the painter's tape to the outside of the top and bottom lines, applying pressure to ensure a tight seal with the walls.
- Step 6** Using the woven roller, paint the accent color inside the taped lines; use the angled brush in corners.
- Step 7** Remove the painter's tape while paint is still damp; clean up any mistakes with the clean, damp cloth; allow paint to dry, following suggested drying time on the can label.

Find more paint projects at menards.dutchboy.com/projects.

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Walls: **Whispered White 019W**
Stripe: **Mousey Tint 441-1DB**
Door: **Pinked Azalea 103-6DB**