SHOWSTOPPING STRIPES

Striped Accent Wall

Earn your stripes with bold bands of color. Plan your stripe strategy and make a playful statement with big impact.

You'll Need:

Dutch Boy® Platinum® Plus paint (2 colors) Woven roller covers and roller frame Angled paintbrush Paint tray and liners Painter's tape

Tape measure Pencil Level Drop cloth Clean, damp cloth



Wall: Garden Stone 437-2DB Stripes: Steely Expression 435-6DB

Here's How:

- **Step 1** Wipe wall with the clean, damp cloth to prepare painting surface.
- **Step 2** Lay down the drop cloth to protect floors; use painter's tape to cover trim, molding, ceiling and any adjacent walls.
- **Step 3** Apply paint just inside taped area with the angled brush, then paint remainder of the wall with the woven roller; remove painter's tape while paint is still damp; allow paint to dry 24 hours.
- **Step 4** Find the middle point of the wall and lightly mark 6 inches on either side with the pencil; from each of these marks, measure and mark 12-inch stripe intervals until you reach each corner of the wall.
 - Tip: For consistent stripes, measure the width of the wall to determine the number and width of stripes. You may need to increase or decrease stripe width (12–inch width shown in picture) based on your wall width to avoid ending on an incomplete stripe.
- **Step 5** Use the level and pencil to lightly mark vertical lines the height of the wall.
- **Step 6** Once stripes are drawn, starting at one end, place a small piece of tape inside every other stripe; the unmarked stripes are to be painted the accent color.
- **Step 7** Affix painter's tape along vertical lines, making sure the edge of the tape is positioned inside the marked stripes; apply pressure to tape to ensure a tight seal with wall.
- **Step 8** Use the woven roller to paint between taped areas of unmarked stripes; roll as close to ceiling and trim as possible and fill in gaps with angled brush.
- **Step 9** Remove the painter's tape while paint is still damp; clean up any mistakes with the clean, damp cloth; allow paint to dry for 24 hours.

Find more paint projects at **menards.dutchboy.com/projects**.

See paint can labels for application instructions and drying times. Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.

