

OLD DOOR, NEW TRICK

Reclaimed Barn Door

Add interest to an entryway and revive a reclaimed door by converting it into a stylish slider. A coat of high-impact color unlocks even more designer flair.

You'll Need:

Dutch Boy® Cabinet, Door & Trim paint	Putty knife
Reclaimed or new door	Wood glue or all-purpose adhesive
Rolling door hardware kit	Fine- to medium-grit sandpaper
Flat paintbrush	Screwdriver
Paint tray and liners	Clean, damp cloth
Wood filler	

Here's How:

Step 1 Remove door hardware; fill oversized areas, such as doorknob holes, with a piece of wood cut to size and glued into place; fill smaller holes with wood filler and the putty knife to create a smooth surface; allow to dry completely.

Tip: Faux barn doors can be purchased either alone or as part of a rolling door installation kit.

Step 2 Lightly sand any rough or glossy surfaces; wipe with clean, damp cloth to remove dust or debris.

Step 3 Using the flat brush, paint the door; allow paint to dry, following suggested drying time on the can label.

Optional: Apply a second coat of paint for added durability.

Step 4 Install door and rolling door hardware according to the directions in the kit.

Find more paint projects at menards.dutchboy.com/projects.

See paint can labels for application instructions and drying times.

Use Dutch Boy® paint to ensure precise color match. Refer to the actual color chip for accurate color representation.



Door: **Flint Stone 433-5DB**
Wall: **Shale Ridge 421-3DB**
Cabinets and Trim: **Classical Ivory 013W**